



DOOR BOTTOM MOUNTED WEATHER BARRIERS

Ultrafab Door Sweeps and Astragal assemblies allow for easy positioning and mounting. They minimize air flow and water penetration through an otherwise unsealed gap. The Polypropylene fibers and center fin are flexible, yet strong; allowing for optimal sealing capabilities along with longer product life compared to other typical options. The color options are black, white, gray and filament/fin. Available bracket combinations are flush mount, bottom mount and right angle mount.

KEY FEATURES

- Reduces or eliminates air and water penetration
- Adjustable aluminum mounting bracket allows for maximum sealing location at door bottom
- Flexible filament and fin combination allows for sealing flexibility, which reduces tearing and sealing failure over extended use
- Ultrasonically welded polypropylene filament and fin assembly for industry leading durability and longevity
- Easy installation

INSTALLATION GUIDE

Horizontal Sweep

1. Measure the full width of the door bottom on the inswing side.
2. If needed, mark and cut the door sweep to that length.
3. Close the door and place the door sweep along the insweep side, bottom edge of the door so that the brush firmly touches the floor.
4. Mark on the door in the center of each pre-punched slot.
5. Drill small pilot holes at each mark.
6. Secure door sweep to the door with supplied screws. Adjust the door sweep to ensure firm contact with the floor but do not over compress.

Vertical Sweep

1. Measure the full height of the door on the inswing, lock set aside.
2. If needed, mark and cut the door sweep to length.
3. Close the door and place the door sweep along the edge of the inswing, lock set aside. (This may take two people.) Door sweep brush should slightly overlap door frame.
4. Drill small pilot holes at each mark.
5. Secure door sweep to the door with supplied screws. Adjust the door sweep to ensure even coverage from top to bottom.

TOOLS REQUIRED

- Tape Measure, Pencil, Saw, Screwdriver, Electric Drill.
- All Ultrafab Door Sweeps include color matching screws for a professional finished look as well as easy installation instructions.

